



**Abyss S1560 Multi-Color Remote Controlled  
Underwater LED Light Kit  
Operating Instructions**  
Page 1 of 3

Specs:

Choose among 16 solid colors or dynamic patterns

Over 4,000 light color/intensity combinations can be selected with the included remote control

Choose among 15 unique lighting patterns

Each pattern can be set to 30 unique speeds

Over 1,800 pattern/speed/color combinations can be selected with the included remote control

The S1560 Kit includes:

Two S1560 LED underwater lights

Wireless remote with up to 10 foot range

Wireless remote receiver

Power converter

Operating instructions:

To select a solid color, push the button corresponding to the color.

Use the +/- buttons to adjust brightness of light output.

To select a pattern, push one of the following pattern buttons: flash, strobe, fade, or smooth.

Pushing the same pattern button consecutively will cycle through the additional patterns in the group. For example, press the strobe button twice to activate the "strobe - 2" pattern described below.

Flash pattern

**Flash - 1: Alternates amongst seven colors.**

Adjust speed of pattern with +/- buttons.

To return to solid color light output (non-flashing), press any color button.

Strobe patterns

**Strobe – 1: White light fades on/off with pulsing "heartbeat" effect.**

Adjust speed of pattern with +/- buttons.

To return to solid color light output (non-flashing), press any color button.

**Strobe – 2: Strobe "police" pattern, alternates red/blue/purple, with four short flashes per color.**

Adjust speed of pattern with +/- buttons.

To return to solid color light output (non-flashing), press any color button.

**Strobe – 3: Strobe “police” pattern with single color output. Four short flashes, then dark, then four short flashes, etc.**  
Adjust speed of pattern with +/- buttons.  
Select color for this pattern by pressing any color button.

#### Fade patterns

**Fade – 1: Alternates amongst seven colors, with fade to dark between colors.**  
Adjust speed of pattern with +/- buttons.  
To return to solid color light output (non-flashing), press any color button.

**Fade – 2: Alternates amongst seven colors. Blends from one color to the next with no fade to dark between colors.**  
Adjust speed of pattern with +/- buttons.  
To return to solid color light output (non-flashing), press any color button.

**Fade – 3: Single color on 2 seconds, off 1 second, on 2 seconds, etc.**  
Adjust speed of pattern with +/- buttons.  
Select color for this pattern by pressing any color button.

#### Smooth patterns

**Smooth – 1: Single color on 1 second, off 1 second, on 1 second, etc.**  
Adjust speed of pattern with +/- buttons.  
Select color for this pattern by pressing any color button.

**Smooth – 2: Alternates among red and green with rapid color change.**  
Adjust speed of pattern with +/- buttons.  
To return to solid color light output (non-flashing), press any color button.

**Smooth – 3: Alternates among red, green, and yellow with rapid color change.**  
Adjust speed of pattern with +/- buttons.  
To return to solid color light output (non-flashing), press any color button.

**Smooth – 4: Alternates among red, green, and blue with rapid color change.**  
Adjust speed of pattern with +/- buttons.  
To return to solid color light output (non-flashing), press any color button.

**Smooth – 5: Alternates among red, green, blue, and white with rapid color change.**  
Adjust speed of pattern with +/- buttons.  
To return to solid color light output (non-flashing), press any color button.



**Abyss S1560 Multi-Color Remote Controlled  
Underwater LED Light Kit  
Operating Instructions  
Page 3 of 3**

**Smooth – 6: Complex pattern: rapid change between red, green, blue, red, green, blue, red, green, blue, red, white, dark, white, dark, white, red.**

Adjust speed of pattern with +/- buttons.

To return to solid color light output (non-flashing), press any color button.

**Smooth – 7: Complex pattern: rapid change between red, green, blue, red, green, blue, red, green, blue, red, yellow, dark, yellow, dark, yellow, red.**

Adjust speed of pattern with +/- buttons.

To return to solid color light output (non-flashing), press any color button.

**Smooth – 8: Complex pattern with a variety of flashing and fading effects with various colors.**

Adjust speed of pattern with +/- buttons.

To return to solid color light output (non-flashing), press any color button.